FireLinc™

PROTECT YOUR DEPARTMENT WITH CLEANER GEAR

AND THE RECORDS TO BACK IT UP.

 SYNC WITH YOUR INVENTORY TRACKING SYSTEM

 SORT BY EQUIPMENT ID, LOCATION AND WHO COMPLETED WASH

 SEE WHAT MACHINE—AND WHICH CYCLE—WAS USED

 EXPORT WASH HISTORY TO SPREADSHEET FOR EASY AUDITING

FireLinc App
Available on Google Play.

GET IT ON Google Play

FireLinc™

SYSTEM REQUIREMENTS

UniMac®
Maximum Performance

BASIC
Compatible With All UniMac Controls

THESE MATERIALS ARE REQUIRED TO CONNECT YOUR TABLET TO YOUR WASHER-EXTRACTOR:

*Android tablet
(Marshmallow operating system or newer)
*Needs power

Articulating arm
(Connects the tablet to washer)

20' USB to micro-USB power cable
(Allows your tablet to receive power from a distant source)

Wi-Fi internet connection

MANUAL ENTRY

INTERMEDIATE
Compatible With All UniMac Controls

TO EXPEDITE THE DATA-ENTRY PROCESS VIA SCANNED ENTRY, THE FOLLOWING ITEMS ARE REQUIRED:

Choose one of the two types of data readers:

RFID reader   **Barcode reader**

OR

PLUS

#10 1.5" coarse-thread screw

3M exterior mounting tape

14" nylon zip ties
(4 minimum per install)

120-volt power/1 power strip

6' audio cable extension
(RFID reader only)

SCANNED ENTRY

PREMIUM
Compatible With All UniMac Machines Equipped With UniLinc™ Controls

FULL REPORTING IS AVAILABLE WITH TotalVue™, WHICH IS…

- EASY TO SET UP
- EASY TO ACCESS
- EASY TO USE
- EASY TO UNDERSTAND

YOU'LL ALSO NEED:

Wireless Network Board
Machines purchased before 4/1: NK301
Machines purchased after 4/1: F8662201

AND

Ethernet Gateway: NK320

OR

Cellular Gateway Kit
for cloud connectivity: 203993

SCANNED ENTRY WITH FULL REPORTING